



# Deltacom Bluetooth Instructions

## Deltacom 200S Master Unit with Bluetooth

To pair a new bluetooth device to the system:

Scan for other Bluetooth devices on the device you wish to connect. The Deltacom Bluetooth Module will be displayed with a number such as "BT-163" or "BT-118". Then pair using the menu on your device. If prompted for a PIN, enter 0000.

To connect a previously paired device to the system:

Go to the Bluetooth menu on your previously paired device and select the Deltacom Bluetooth Module (i.e. BT-163 or BT-118)

To disconnect, either turn off Bluetooth on your Bluetooth device or use the Bluetooth menu on your device to drop the connection with the Deltacom Bluetooth Module.

To hear music from the Bluetooth connected device follow these steps:

If it is the first time Bluetooth is used after turning power on to the intercom system:

1. Press "Radio On/off" button twice on the 200 Master unit
2. Press "Music" button on the 200 Master or on any room units when you want to hear the music
3. Play music from Bluetooth device.
4. Press "Music" button again to mute the music.

All other times:

1. Ensure radio is turned off.
2. Press "Music" button on the 200 Master or on any room units when you want to hear the music
3. Play music from Bluetooth device.
4. Press "Music" button again to mute the music.

Notes:

- The range of Bluetooth for this system is approximately 5 metres. This can be reduced by walls and obstructions.
- If you move out of range while connected to Bluetooth, Bluetooth will disconnect. If you move back into range within approx 3 minutes it will automatically reconnect. If you are out of range for longer than approx. 3 minutes you will need to connect the device as described above.